




## INSTALLATION AND MAINTENANCE MANUAL FOR HERMETIC SLIDING DOOR



**SL6HA HERMETIC-ADVANCED**  
**SL6HB HERMETIC-BIG**

## 1. INTRODUCTION

Before you begin to install or start an automatic pedestrian doors, an inspection must be carried out on site by qualified personnel, for making measurements of the compartment wall, door and drive.

This inspection is to assess the risk and to select and implement the most appropriate solutions according to the type of pedestrian traffic (intense, narrow, one-way, bi-directional, etc.), The type of users (elderly, disabled, children, etc.), in the presence of potential hazards or local circumstances.

To assist installers in applying the requirements of European Standard EN 16005 concerning the safe use of automatic pedestrian doors, we recommend consulting the guides E.D.S.F. (European Door and Shutter Federation) available on [www.edsf.com](http://www.edsf.com).

### 1.1 GENERAL SAFETY INSTRUCTION

This installation manual is intended for professionally competent personnel only. Before installing the product, carefully read the instructions.

Bad installation could be hazardous. The packaging materials (plastic, polystyrene, etc.) should not be discarded in the environment or left within reach of children, as these are a potential source of hazard.

Before installing the product, make sure it is in perfect condition. Do not install the product in an explosive environment and atmosphere: gas or inflammable fumes are a serious hazard risk.

Before installing the automations, make all structural changes relating to safety clearances and protection or segregation of all areas where there is risk of being crushed, cut or dragged, and danger areas in general.

Make sure the existing structure is up to standard in terms of strength and stability. FACE is not responsible for failure to use Good Working Methods in building the frames to be motorised or for any deformation occurring during use.

The safety devices (safety sensor, photocells, etc.) must be installed taking into account: applicable laws and directives, Good Working Methods, installation premises, system operating logic and the forces developed by the motorised door.

Apply hazard area notices required by applicable regulations.

The emission sound pressure level of the door is  $LpA \leq 70dB(A)$ .

Each installation must clearly show the identification details of the automatic pedestrian door.

The product, in its original packaging supplied by the manufacturer, must only be transported in a closed environment (railway carriage, containers, closed vehicles).

If the product malfunctions, stop using it and contact an authorised support centre.

The manufacture date is provided in the production batch printed on the product label. If necessary, contact us at [www.facespa.it](http://www.facespa.it).

The general conditions of sale are given in the official FACE price lists.

### 1.2 CE MARKING AND EUROPEAN DIRECTIVES



Automations for sliding pedestrian, are designed and manufactured in compliance with the safety requirements of the European standard EN 16005 and are CE-marked in accordance with the Electromagnetic Compatibility Directive (2014/30/UE).

The automation also include a Declaration of Incorporation according to the Machinery Directive (2006/42/EC).

Pursuant to Machinery Directive (2006/42/CE) the installer who motorises a door or gate has the same obligations as the manufacturer of machinery and as such must:

- prepare the technical file which must contain the documents indicated in Annex V of the Machinery Directive; (The technical file must be kept and placed at the disposal of competent national authorities for at least ten years from the date of manufacture of the pedestrian door);
- draft the EC declaration of conformity in accordance with Annex II-A of the Machinery Directive and deliver it to the customer;
- affix the CE marking on the power operated door in accordance with point 1.7.3 of Annex I of the Machinery.

All data and information contained in this manual have been drawn up and checked with the greatest care. However FACE cannot take any responsibility for eventual errors, omissions or inaccuracies due to technical or illustrative purposes.

FACE reserves the right to make changes and improvements to their products. For this reason, the illustrations and the information appearing in this document are not definitive.

This edition of the manual cancels and replaces all previous versions. In case of modification will be issued a new edition.



## DECLARATION OF INCORPORATION

Machines Directive 2006/42/EC, Annex II-B



FACE S.r.l.

Viale delle Industrie, 74 - 31030 Dosson di Casier (TV) - ITALY

### Declares that:

The Product automations for power operated pedestrian sliding door type: **SL6HA, SL6HB**.

Has been built for installation on pedestrian door and constitutes a machine in accordance with Directive 2006/42/EC. The manufacturer of the power operated pedestrian door must declare its conformity in accordance with Directive 2006/42/EC (Annex II-A) prior to starting-up the machine.

It complies with the applicable essential safety requirements specified in Annex I, chapter 1 of Directive 2006/42/EC:

1.1.2, 1.1.3, 1.2, 1.3.1, 1.3.2, 1.3.4, 1.3.7, 1.3.8, 1.4, 1.5.1, 1.5.2, 1.5.10, 1.5.11, 1.5.14, 1.6.1, 1.6.3, 1.7

It complies with the Electromagnetic Compatibility Directive 2014/30/UE.

It complies with following harmonized standards:

EN 16005 Power operated pedestrian doorsets - Safety in use - Requirements and test methods

EN 60335-2-103 Household and similar electrical appliances - Safety - Part 2: Particular requirements for drives for gates, doors and windows

The technical documentation complies with Annex VII-B to Directive 2006/42/EC.

The technical documentation is managed by: Ferdinando Menuzzo with registered offices in Viale delle Industrie, 74 - 31030 Dosson di Casier (TV) - ITALY

A copy of the technical documentation shall be supplied to the competent national authorities following duly motivated request.

Place and date:

Dosson di Casier, 2022-09-01

Paolo Bacchin  
Managing Director

A blue ink signature of Paolo Bacchin, written over the printed name and title.

### FACE S.r.l.

Viale delle Industrie, 74

31030 – Dosson di Casier (TV) Italy

Phone +39 0422 492730 Fax +39 0422 380414

[www.facespa.it](http://www.facespa.it)











Iscritta al Reg. Imp. di Treviso al n. 04552520266

C.F.-P.I. 04552520266

Capitale Sociale € 100.000,00 i.v.

R.E.A. di Treviso n. 359250

## 2. TECHNICAL DATA


Features	SL6HA	SL6HB
Automation type	HEAVY	BIG
Certification		
Max product dimensions: Height x Depth x Maximum lenght	125 x 156 x 6600 mm	125 x 156 x 6600 mm
Maximum weight of door	1 x 100 kg	1 x 200 kg
Maximum opening and closing speed	0,8 m/s	0,3 m/s
Duty class Intermittent operation	Intensive operation S3 = 60%	Intensive operation S3 = 60%
Power supply Rated power Stand-by	100–240 Vca 50/60 Hz 70 W 10 W	100–240 Vca 50/60 Hz 70 W 10 W
Rated load	150 N	350 N
Protection Rating	IP 20	IP 20
Operating temperature Storage temperature (*)	 -15 °C  +50 °C  -20 °C  +70 °C	 -15 °C  +50 °C  -20 °C  +70 °C
Average life (**)	1.000.000 cycles	1.000.000 cycles
Power output for accessories	12 Vdc (1 A max)	12 Vdc (1 A max)
Memory for settings and saving	USB / micro SD	USB / micro SD
Electronic function selector	FSD5, FSD6	FSD5, FSD6
Safety braking device	SL5SB4	SL5SB4
Battery power device	SL5BD, SL5BD2	SL5BD, SL5BD2

(\*) Before installing the product, keep it at room temperature where it has previously been stored or transported at a very high or very low temperature.

(\*\*) The average product life specified should be understood purely as an indicative estimate. It applies to normal usage conditions and where the product has been installed and maintained in compliance with the instructions provided in the technical manual. The average product life is also affected, including significantly, by other variables such as, but not limited to, climatic and environmental conditions. The average product life should not be confused with the product warranty.

Note: The technical data above refer to average conditions of use and cannot be certain in each case. Each automatic entrance variables such as: friction, balancing and environmental conditions may substantially change both the duration and the quality of the operation of the automatic entrance or some of its components, including the automation. The installer must adopt adequate safety coefficients for each particular installation.

### 3. STANDARD INSTALLATION



Rif.	Code	Description
1	SL6HA120R/L – SL6HA166R/L	SL6HA automation (Hermetic-Advanced) for hermetic sliding doors
	SL6HB120R/L – SL6HB166R/L	SL6HB automation (Hermetic-Big) for hermetic sliding doors
2	OSD5	Safety sensor
3	OSD5 + CFSS	Safety sensor fixed in the upper part of the door frame
4	OSD5 + CFSSIN	Safety sensor fixed inside the automation
5	EB1	Elbow switch device
	TD2, TD3	Proximity opening sensor
6	FSD5, FSD6	Electronic function selector

Note: Components and codes are those most commonly used in systems for automatic sliding doors. The full range of equipment and accessories is also available in the sales list.

The given operating and performance features can only be guaranteed with use of FACE accessories and safety devices.

### 4. INSTALLATION PROCEDURE OF THE SLIDING HERMETIC DOOR


SL6H automations for hermetic sliding doors can be installed in combination with SF60H and SF45H hermetic doors supplied by FACE, or with commercial hermetic doors not supplied by us (use the X105-4 form, available at [www.facespa.it](http://www.facespa.it) in the Download area, to communicate the automation data and the information necessary for the order).

To facilitate the calculations and the choice for the ordination of automatic sliding doors, FACE has developed SDC computer program (Sliding Door Configurator), available at [www.facespa.it](http://www.facespa.it) in Download area.


When the door is in the closed position it is lowered by 8 mm and approached to the 8 mm frame, causing compression of the gaskets and obtaining a hermetic closure.

Respect the vertical and horizontal dimensions shown in the following figures.


#### 4.1 SF45H HERMETIC DOOR WITH RIGHT OPENING




## 4.2 SF45H HERMETIC DOOR WITH LEFT OPENING



#### 4.3 SF45H HERMETIC DOOR OPENING TO THE RIGHT AND WITH HANDLE



#### 4.4 SF45H HERMETIC DOOR WITH LEFT OPENING AND WITH HANDLE



#### 4.5 INSTALLATION OF THE DOOR

Fixing of the drive unit profile to the wall must be safe and suitable for the weight of the doors. Distribute the fixing points every 500 to 800 mm (or 300÷500 mm for heavy doors) along the present lines on the aluminium profile, using suitable plugs and screws, not supplied by us.

The channel and the holes for the passage of the power cord and cables for connecting the control and safety devices (sensors, function selector, buttons, etc.), must be prepared and executed.

Fix the sliding door (Lm) to the carriages by means of screws [a], as shown in the figure.


Bring the leaf to the open position and make height adjustments using screws [b] and [c], and make depth adjustments using screws [a].

Move the leaf by hand along the run and check that the movement is free and without friction.

Check that in the closed position the door is lowered by 8 mm and moved closer to the 8 mm frame, causing compression of the gaskets and obtaining a hermetic closure.

Check that the lower part of the door is correctly guided by the floor bracket.


Adjust the position of the mechanical stop brackets [d] near the heads, so as to limit the run of the leaf in the closing and opening positions.



#### 4.6 BELT ADJUSTMENT

Adjust the tension of the belt with the transmission unit as shown in the figure:

- Manually push to left the transmission unit, so as to tension the belt, and attach it to the drive unit profile by screws,
- Loosen the screws [a],
- Tighten the screw [b] and compress the spring until 18 mm (always check manually, the belt tension is not too tight or too loose),
- Lock the adjustment of the belt tension by tightening the screws [a].




#### 4.7 AUTOMATION CLOSING


Hang the cover profile to the drive unit profile. The drive unit profile is kept closed by magnets on the end caps.

In the upper slot between the cover and the automation profile, apply the supplied gasket to prevent the accumulation of dust.


Make the sealing between the wall and the automation to avoid the accumulation of dust.



Note: To avoid that the cover can be opened without the use of a tool, it is necessary to make two 5 mm holes in diameter at the ends of the cover profile, as shown in the figure, and fix the cover with the screws 4,8 x13 provided.



## 5. ELECTRICAL CONNECTIONS



Ref.	Code	Terminals	Description
1	3EW250V	MAINS IN	Cable for connection to the power supply.
2	5CB01		Electronic control
3	5B90SL	MOT ENC	Brushless motor Angular sensor
4	SL5BD, SL5BD2	BAT	Battery power device
5		FUSE	Battery fuse 5x20 - F16A
6	SL5SB4	LK	Safety braking device

## 5.1 GENERAL SAFETY ELECTRICAL PRECAUTIONS

Installation, electrical connections and adjustments must be completed in conformity with Good Working Methods and with regulations in force.

Before making power connections, check that the rating corresponds to that of the mains supply. A multipolar disconnection switch with a contact opening gap of at least 3 mm must be included in the mains supply. This switch must be protected from unauthorized activations.

Check that, upstream of the electrical installation, an adequate residual current circuit breaker and an overcurrent cut out are fitted.

Connect the automation to an effective earthing system carried out as indicated by current safety regulations.

During installation, maintenance and repair operations, cut off the power supply before opening the cover to access the electrical parts. To handle electronic parts, wear earthed antistatic conductive bracelets.

FACE declines all responsibility in the event of components which are not compatible with the safe and correct operation of the product.

For repairs or replacements of products only original spare parts must be used.

## 5.2 POWER SUPPLY ELECTRICAL CONNECTION

Use the supplied cable for connection to electricity.

The power cable can be connected to an electric plug (not supplied by us), arranged near the end cap of the automation.

Drill a hole in the end cap area prepared, route the power cord and secure it inside the end cap through the cable tie.


Note: file off the edge of the aluminum, so as to eliminate sharp edges that might damage the power cable.



In case there isn't a socket near the automation, perform the connection to the power supply in the following manner: drill the aluminum profile in the upper part or in the rear wall fixing, protect the passage of the power cord through membrane grommets or cable glands (not supplied by us) to eliminate sharp edges that might damage the power cable, and connect the cable to the power supply.

The connection to the mains supply in the outer portion automation, should be an independent channel, separated from the connections to control and safety devices.

## 5.3 TERMINAL OF ELECTRONIC CONTROL



Note: The terminals with the same number are equivalent.

The electronic control comes with the jumpers on the terminals with an asterisk [\*]. When connecting safety devices remove the jumpers of the corresponding terminals.

Terminals	Description
0 – 1	Output 12 Vdc for external powering accessories. The maximum absorption of 1 A corresponds to the sum of all the terminals 1 (+12V).
1 – 3A	Contact N.O. opening A side (interior side).
1 – 3B	Contact N.O. opening B side (outer side).
1 – KO	Contact N.O. apen priority, connect to devices accessible only by authorized personnel with keys or codes.
1 – S1	Do not use.
1 – 8A	Safety contact N.C. on doorway side A (interior side). When the door is closing, the opening of the contact causes the reversal of the movement. Note: connect safety devices with test (see terminal 41), and remove the jumper 41 - 8A.
1 – 8B	Safety contact N.C. on doorway side B (outer side). When the door is closing, the opening of the contact causes the reversal of the movement. Note: connect safety devices with test (see terminal 41), and remove the jumper 41 - 8A.
1 – 6A	Opening safety contact N.C. side A (left side). When the door is opening, the opening of the contact causes the slowdown of the door in the last 500 mm (the safety function of the terminal 6 can be changed using the advanced settings menu). Note: connect safety devices with test (see terminal 41), and remove the jumper 41 - 6A.
1 – 6B	Opening safety contact N.C. side B (right side). When the door is opening, the opening of the contact causes the slowdown of the door in the last 500 mm (the safety function of the terminal 6 can be changed using the advanced settings menu). Note: connect safety devices with test (see terminal 41), and remove the jumper 41 - 6A.
41	Test output (+12 V). Connect the safety devices with test (in accordance with EN 16005), as indicated in the following chapters. Note: in case of devices without test, connect the N.C. contact to terminals 41 - 8A or 41 - 8B, or 41 - 6A, or 41 - 6B.
1 – G1/G2/G3/G4 0 – G1/G2	Input terminal provided for general use. Output terminal (12 Vdc, 30 mA max) provided for general use. Using the ADV > STG1/STG2/STG3/STG4 menu you can choose a specific function to the G1/G2/G3/G4 terminal.
0 – 1 – H – L	Bus connection to the function selector.
USB	Standard connection for memory cards USB. Allows saving the door settings and loading the firmware updates.
SD	Standard connection for micro SD memory cards. Allows saving the door settings and loading the firmware updates.
COM	Connection for remote communication.

Buttons	Description
OPEN	Open the door.
↑	Scroll the menu and increase of selected values.
↓	Scroll the menu and reduction of selected values.
ENTER	Button to select the menu and save the selected data.
ESC	Exit the menu.


## 7.4 ELECTRICAL CONNECTION OF FUNCTION SELECTOR











Connect the 0-1-H-L terminals of the function selector, by cable (not supplied by us), to the 0-1-H-L terminals of the electronic control.

Note: for lengths over 10 m, use a cable with 2 twisted-pairs.


ATTENTION: the function selector must be used by authorized personnel only; if it is installed in a place accessible to the public, the function selector must be protected by a proximity badge (13.56MHz ISO15693 and ISO14443 Mifare) or by a numeric code (max 40 badges and codes).

The function selector allows the following settings.



Symbol	Description
	<b>OPEN DOOR</b> When selected, the symbol lights up, the door is permanently open. Note: the leaves can still be handled manually. <b>LOW SPEED OPERATION</b> Select the symbol for 5 seconds (double beep), the AUTOMATIC symbol flashes and the door works without safety sensors with reduced speed. Note: this mode must be used temporarily in the event of a malfunction of the safety sensors.
	<b>AUTOMATIC PARTIAL OPERATION</b> When selected, the symbol lights up and automatic operation of the door is with a partial opening of the leaves.
	<b>AUTOMATIC BI-DIRECTIONAL OPERATION</b> When selected, the symbol lights up, the door works automatic in bidirectional mode. <b>RESET</b> Select the symbol for 5 seconds, the automation performs the self-test and the automatic learning.
	<b>AUTOMATIC ONE-WAY OPERATION</b> When selected, the symbol lights up and automatic operation of the door is in one-way mode.
	<b>CLOSED DOOR</b> When selected, the door is permanently closed. If the locking device is present, the door is closed and locked. Note: using the menu SEL > DLAY you can adjust the delay time to close the door. <b>CLOSING PRIORITY</b> Select the symbol for 3 seconds, the automation closes slowly. Note: if present, the safety sensors are disabled.
	<b>PROTECTED FUNCTION SELECTOR</b> The symbol lights up if the function selector is protected. To activate the temporary operation of the function selector is necessary to approach the badge to the NFC symbol, or enter the code, or select for 3 seconds the logo.
	<b>ACTIVATION OF FUNCTION SELECTOR BY LOGO (SEL&gt;SECL=LOGO)</b> Select the logo for 3 seconds (the lock symbol light off), the function selector is activated for 10 seconds. Expired the time the function selector switches off (the lock symbol lights up). Note: the function selector logo flashes when the CAN bus communication is not working (H-L terminals).
	<b>ACTIVATION OF FUNCTION SELECTOR BY BADGE (SEL&gt;SECL=TAG)</b> Approach the badge to the NFC symbol (the lock symbol light off), the function selector is activated for 10 seconds. Expired the time the function selector switches off (the lock symbol lights up).
<b>1 2 3 4 5</b>	<b>ACTIVATION OF FUNCTION SELECTOR BY NUMERIC CODE (SEL&gt;SECL=TAG)</b> Press the logo, enter the code (maximum 5 numbers), press the logo for confirmation, (the lock symbol light off), the function selector is activated for 10 seconds. Expired the time the function selector switches off (the lock symbol lights up).
	<b>BATTERY SIGNAL</b> Battery symbol off = the door is operating with the mains supply Battery symbol on = the door is operating with battery power Battery symbol flashing = the battery is low or disconnected
	<b>INFORMATION SIGNAL</b> Information symbol on = it is necessary to perform the ordinary maintenance of the door. Information symbol flashing = shows the presence of alarms: - 1 flash = failure of electronic control or locking device; - 2 flashes = mechanical failure; - 3 flashes = failure of sensor safety test; - 4 flashes = motor overtemperature.

5.5 ELECTRICAL CONNECTION OF OPENING AND SAFETY SENSOR




Connect the sensor, using the supplied cable, to the terminals of the electronic control, as follows:

	5CB01	OSD1 (Prime Tec B)	OSD3 (VIO-DT1) OSD4 (IXIO-DT3)	OSD5 (3H-IR14C) OSD6 (HR100-CT) OSD8 (SSR-3-ER)	Notes
OPENING	0	White	Brown	Black	
	1	Brown Yellow	Green Yellow	Red White	
	3A (3B)	Green	White	Green	
SAFETY	0	Gray	Blue	Brown	
	1	Red	Pink	Yellow	
	8A (8B)	Blue	Gray	Blue (OSD6: DIP3Y=ON)	Remove the jumper 41-8A (8B)
	41	Pink	Red	Gray (OSD5: DIP8=ON) (OSD6: DIP6Z=ON)	
			White/Black	Light blue	Do not connect
			Yellow/Black	Pink	Do not connect

For more information, check the installation manual of the sensor.

5.6 ELECTRICAL CONNECTION OF SAFETY SENSOR




Connect the sensor, using the supplied cable to the terminals of the electronic control as follows:

	5CB01	OSD5 (3H-IR14C)	Notes
SAFETY	0	Black Brown	
	1	Red Yellow	
	6A (6B)	Blue	Remove the jumper 41-6A (6B)
	41	Gray (DIP8=ON)	
		White	
		Green	Do not connect

For more information, check the installation manual of the sensor.

## 6. ELECTRONIC CONTROL ADJUSTEMENT

The electronic control has 4 buttons and 4 alphanumeric displays to set all the necessary adjustments. After turning on the electronic control, the display shows the word "MENU". The operation of the four keys are indicated in the table.

Keys	Description	
ENTER	Select button, each time you press the button you enter on the selected parameter. Save button, pressing for 1 seconds you "SAVE" the selected value. There are the following menu: MENU = Main parameters menu ADV = Advanced parameters menu SEL = Function selector menu MEM = Memory management menu INFO = Information and diagnostics menu	
ESC	Exit button, exit from all the parameter or exit from the menu.	
↑	Scroll button, each press selects a menu item or increases the value of the selected item.	
↓	Scroll button, each press selects a menu item or reduces the value of the selected item.	

### 6.1 MENU (MAIN SETTINGS MENU)

Using the buttons ↑ and ↓ choose MENU, press ENTER to select and adjust the following parameters:

(\*) Factory settings

Display	Description
<b>DOOR</b> DOOR TYPE	Setting the automation type. Choose from the following values: <b>STD = standard for automations type: ADVANCED, EMERGENCY, HEAVY, TELESCOPIC</b> BIG1 = for BIG automation with belt gear unit and big pulley HSTD = for HERMETIC automation HBIG = for HERMETIC-BIG automation BIG = for BIG automation (OLD VERSION)
<b>OPEN</b> OPENING DIRECTION	Setting the opening direction. Choose between the following values: <b>↔ → (*) = 2-leaves door or 1-leaf door opening to right</b> ← = 1-leaf door opening to left
<b>PART</b> PARTIAL OPENING	Setting the percentage of partial opening. Choose between the minimum and maximum: minimum value = 10% <b>maximum value = 90% (*)</b>
<b>VOP</b> OPENING SPEED	Opening speed setting. Choose between the minimum and maximum: minimum value = 100 mm/s maximum value = 800 mm/s ( <b>* 500 mm/s</b> ) If the door is heavy, the set speed is automatically reduced to allowed values (see the technical data).
<b>VCL</b> CLOSING SPEED	Closing speed setting. Choose between the minimum and maximum: minimum value = 100 mm/s maximum value = 800 mm/s ( <b>* 300 mm/s</b> ) If the door is heavy, the set speed is automatically reduced to allowed values (see the technical data).
<b>TAC</b> CLOSING TIME	Setting the door closing time. Choose between the minimum and maximum: NO = the door is always open <b>minimum value = 1 s (*)</b> maximum value = 30 s
<b>PUSH</b> MOTOR POWER	Force setting. Choose between the minimum and maximum: minimum value = 1 <b>maximum value = 10 (*)</b>

Display	Description
<b>LEAF</b> DOOR WEIGHT	Setting the weight of the door and the friction. Choose between the following values: NO = without door MIN = light door / little friction <b>MED (*) = middleweight / average friction</b> MAX = heavy door / a lot of friction HEVY = automation HEAVY version, for heavy doors
<b>RAMP</b> ACCELERATION	Set the acceleration time. Choose between the minimum and maximum values: SLOW = slow acceleration <b>MED (*) = medium acceleration</b> FAST = fast acceleration
<b>BTMD</b> BATTERY MODE	Setting operation of battery power device, in absence of electricity. Choose between the following values: <b>NO (*) = battery not connected</b> EMER = emergency open CONT = continuation of normal operation of the door Note: the number of operations with battery, depends on the efficiency of the battery, the weight of the doors and the present friction. UNLK = the locking device is released and the door remains stationary. FIRE = priority closing of the door for fire alarm. Note: If the automatic door is turned off for long periods, disconnect the battery from the electronic board.

## 6.2 ADV (ADVANCED PARAMETERS MENU)

Using the buttons ↑ and ↓ select ADV, press ENTER to select and adjust the following parameters.

(\*) Factory settings

Display	Description
<b>OSSM</b> OPENING SAFETY MOTION	Setting the slowdown distance of the opening sensors (see 6A/6B terminals). Choose between the following values: NO = no slowdown 100 / 200 / 300 / 400 / 500 = the door slows down in the last 100/ 200/ 300/ 400/ 500 mm of opening <b>YES (*) = the door slows down during the whole opening</b>
<b>OSSS</b> OPENING SAFETY STOP	Setting the stopping distance of the opening sensors (see 6A/6B terminals). Choose between the following values: <b>NO (*) = no stop</b> 100 / 200 / 300 / 400 / 500 = the door stops in the last 100/ 200/ 300/ 400/ 500 mm of opening
<b>TYLK</b> LOCK TYPE	Selecting type of locking device. Choose between the following values: <b>LK1 (*) = bistable locking device (SL5LD)</b> LK2 = safety brake device 24Vdc 0,1÷0,4A (SL5SB1, SL5SB3, SL5SB4, SLT5B) LK3 = monostable locking device 12-24Vdc 0,2÷0,6A (SL5LD1) LK4 = monostable anti-panic locking device 12-24Vdc 0,2÷0,6A (SL5LD1)
<b>ELLK</b> LOCK OPERATION TYPE	Selecting type of lock operation. Choose between the following values: <b>AUTO (*) = unlocked with automatic operation while locked with unidirectional operation and door closed</b> UNLK = always unlocked with automatic operation and unidirectional LOCK = always locked the door closed (if TYLK=LK2, LOCK = always locked with door closed and open)
<b>FILK</b> LOCK OPERATION FIRE	Selection of the type of operation of the locking device in the event of a fire alarm (FIRE). ELLK = the locking device works as set in the ELLK parameter UNLK = the locking device is unlocked <b>LOCK (*) = the locking device is locked</b>
<b>PUCL</b> PUSH DOOR CLOSED	Setting the push on the closed mechanical stop. Choose between the following values: NO = no push <b>MIN (*) = light push</b> MED = medium push MAX = heavy push
<b>PIPP</b> PUSH DOOR OPEN	Setting of the opening push. Choose between the following values: <b>NO (*) = no push</b> YES = push enabled

Display	Description
<b>HOLD</b> HOLD DOOR OPEN	Setting the push of keeping the door open (TO BE USED WITH THE KSLF/KSLFT DEVICE). Choose between the following values: <b>NO (*) = no push</b> MIN = light push MED = medium push MAX = heavy push
<b>PUGO</b> PUSH & GO	Push opening activation. Choose between the following values: <b>NO (*) = disable</b> YES = enable
<b>TAKO</b> KO-CLOSING TIME	Setting the door closing time, after the 1-KO command. Choose between the minimum and maximum: <b>NO (*) = see MENU &gt; TAC</b> minimum value = 1 s maximum value = 30 s
<b>VTAC</b> VARIABLE CLOSING TIME	Automatic closing time variable in relation of pedestrian traffic. Choose between the following values: NO = disable <b>YES (*) = enable</b>
<b>MOT</b> MOTOR CIRCUIT	Setting the manual friction of the door (only with power supply), by means of the electrical connection of the motor windings. Choose between the following values: <b>OC (*) = manual door opening without friction (motor with open circuit windings)</b> SC = manual door opening with friction (motor with short-circuit windings)
<b>T41</b> SAFETY TEST	Enable test for safety devices (in accordance with EN 16005). Choose between the following values: NO = test disabled (NOT COMPLY TO EN 16005) <b>YES (*) = test enable</b>
<b>EMER</b> EMERGENCY DOOR	For EMERGENCY automation only. If necessary, you can turn off the operation as an emergency exit. Choose between the following values: NO = emergency exit disabled (not comply to EN 16005) <b>YES (*) = emergency exit enabled</b> MAX = emergency exit enabled (for doors with high friction)
<b>PULY</b> MOTOR PULLEY	Set the type of motor pulley. Choose between the following values: <b>15 (*) = WHITE motor pulley with 15 teeth</b> 18 = BLACK motor pulley with 18 teeth (old version)
<b>SYNC</b> DOOR SYNCHRO- NIZATION	Two single-leaf automations with synchronized movement. Choose between the following values. <b>NO (*) = no synchronism</b> MST1 = automazione MASTER automation SLV1 = automazione SLAVE automation MST2 = MASTER external automation (see menu: ADV > INK > EXT) SLV2 = SLAVE external automation (see menu: ADV > INK > EXT)
<b>INK</b> INTER-LOCKED DOOR	Interlocked operation of two automatic doors, the opening of a door is permitted only when the other door is closed. Choose between the following values. <b>NO (*) = no interlock</b> INT = internal door EXT = external door
<b>ID</b> ID NUMBER	If several automations are connected to the network via the 1-H-L terminals, they must have different identification numbers. Choose between the following values: <b>NO (*) = no network</b> 0 / 1 / 2 / 3 / 4 / 5 / 6 / 7 / 8 / 9 / 10 / 11 / 12 / 13 / 14 N.B. After changing the ID, turn the automation off and on again.
<b>PC</b> CLOSING PUSH	Independent setting of the closing force. Choose between the following values: <b>NO (*) = see MENU &gt; PUSH (same force in opening and closing)</b> minimum value = 1 maximum value = 10 Note: if necessary, the closing force (PC) can be set differently from the opening force (PUSH).

Display	Description
<b>STG1</b>	INPUT COMMANDS BETWEEN 1-G1, 1-G2, 1-G3, 1-G4 TERMINALS <b>NO (* STG1 / STG2 / STG3) = no function</b>
<b>STG2</b>	STOP = Stop contact N.C. The opening of the contact stops the door
<b>STG3</b>	FIRE = Priority closing command (N.C.), for fire alarm.
<b>STG4</b>	STEP = Step-by-step contact N.O. The closing of the contact performs in sequence the opening (disabled automatic closure) and the closing of the door.
<i>Setting of G1, G2, G3, G4 input</i>	SAM = Automatic setting command of function selector. The closing and the opening of the contact changes the function selector mode (see menu settings: SEL > SAM1 and SEL > SAM2). EMER = Emergency opening contact N.C. The opening of the contact opens the door. PART = Partial opening contact N.O. (see menu: MENU > PART > 10-90). CAB = Step-by-step contact N.O. The closing of the contact performs in sequence the closing of the door (disabling 3A/3B terminals, enabling the signaling for occupied cabin) and the opening of the door (enabling 3A/3B terminals, disabling the signaling for occupied cabin). INKE = Interlocked operation exclusion command between two doors (see menu: ADV > INK) RSET = Reset command <b>KC (* STG4) = Priority closing command (N.O.)</b> SUL = Command to unlock the function selector for 10 seconds
<b>STG1</b>	OUTPUT SIGNALS BETWEEN 0-G1, 0-G2 TERMINALS (12Vdc 30mA) <b>NO (*) = no function</b>
<b>STG2</b>	BELL = The output is activated for 3 seconds when people enter the store (through the sequential activation of the safety contacts: 1-8B and 1-8A).
<i>Setting of G1, G2 output</i>	SERV = The output is activated when the door reaches the number of maintenance cycles, set using the menu: INFO> SERV. WARN = The output is activated when at least one warning remains active for 5 minutes. For remove the alarm signal make a reset or turn off the power supply. CLOS = The output is activated when the door is closed OPEN = The output is activated when the door is open LOCK = The output is activated when the door is closed and locked AIR = The output is activated when the door is not closed LAMP = The output is activated when the door is moving CABS = Signaling of the occupied cabin (see menu: ADV > STG1 > CAB) INK = Red traffic light signaling for interlocked doors (see menu: ADV > INK) PWOFF = The output is activated in the absence of power supply (W128) HAND = The output is activated when the door is opened by hand FS = The output is activated when the door is not closed, in the presence of a fire alarm. 3AS = The output is activated when input 3A is not active 3BS = The output is activated when input 3B is not active SRES = The output is activated when a reset is performed (W127) EMTS = The output is activated while performing the emergency opening test every 24 hours. (for EMERGENCY only).

(\*) Factory settings. ATTENTION: terminals G1, G2, G3, G4 cannot have the same settings.

### 6.3 SEL (FUNCTION SELECTOR MENU)

Using the buttons ↑ and ↓ select SEL, press ENTER to select and adjust the following parameters.

(\*) Factory settings

Display	Description
<b>MODE</b> SELECTOR MODE	Displaying of operating mode of function selector device. Choose between the following values: <b>NO (*) = no mode</b> OPEN = open door AUTO = automatic bi-directional operation CLOS = closed door 1D = automatic one-way operation PA = automatic partial operation 1DPA = automatic one-way operation and partial
<b>SECL</b> SELECTOR LOCK	How to activate the function selector. Choose between the following values: <b>NO (*) = function selector always accessible</b> LOGO = function selector accessible by selecting the logo for 3 seconds TAG = function selector accessible with badge and numeric code
<b>DLAY</b> DELAY CLOSED DOOR	Setting delay time function closed door. Choose between the minimum and maximum values: <b>minimum value = 1 s (*)</b> maximum value = 5 min
<b>TMEM</b> TAG MEMORISE	Saving procedure of badge and numeric code for function selector. Choose between the following values. <b>NO (*) = no saving</b> SMOD = Saving badge and numeric code for activation of the function selector. OPEN = Saving badge and numeric code for activation of priority opening: proceed as SMOD - press the ENTER button for 1 second, the display shows REDY, FSD5 - approach the badge to the function selector (in front of the NFC symbol), the display shows the badge code, FSD6 - press the logo, enter the code (from 1 to 5 numbers), press the logo for confirmation, the display shows the numeric code (Note: the numeric code can be stored only if SECL=TAG), - wait for 2 minutes or press the ESC button. Note: if the badge and the numeric code is not recognized the display shows the message UNKN. You can store a total maximum of 40 badges and numeric codes. APP = Saving phone for activation of the FACE PRC and FACE URC App - press the ENTER button for 1 second, the display shows REDY, FSD5 – stay with the phone near the function selector (in the Bluetooth range). - wait for 2 minutes or press the ESC button.
<b>TMAS</b> TAG MASTER	It is possible to create master badge and master numeric code that allows the saving of the badges and the numeric codes, without the use of the menu. Choose from the following values. <b>NO (*) = no saving</b> MMOD = creation of the master badge and master numeric code to saving badges and numeric codes for function selector activation: proceed as SMOD. MOPE = creation of the master badge and master numeric code to saving the badges and numeric codes of opening priority: proceed as OPEN. Note: if the badge and the numeric code is not recognized the display shows the message UNKN. FSD5 - The use of the master badge is the following: - approach the master badge to the function selector (in front of the NFC symbol), the buzzer emits 2 beeps at the beginning of the storage procedure, - approach the badges, that you want to store, one at a time, to the function selector (in front of the NFC symbol), the buzzer emits 1 beep of confirmation storage, - wait for 2 minutes, the buzzer emits 2 beeps at the end of the storage procedure. FSD6 - The use of the master numeric code is the following: - press the logo, enter the master numeric code, press the logo for confirmation, the buzzer emits 2 beeps at the beginning of the storage procedure, - press the logo, enter the new code (from 1 to 5 numbers), press the logo for confirmation, the buzzer emits 1 beep of confirmation storage, - wait for 2 minutes, the buzzer emits 2 beeps at the end of the storage procedure. Note: if the badge and the numeric code is not stored, the buzzer emits no beeps.

Display	Description
<b>TDEL</b> TAG DELETE	<p>Cancellation procedure of badge and numeric code. Choose between the following values.</p> <p><b>NO (*) = no cancellation</b></p> <p>YES = badge and numeric code cancellation</p> <p>- press the ENTER button for 1 second, the display shows REDY,</p> <p>FSD5 - approach the badge to the function selector (in front of the NFC symbol), the display shows the badge code,</p> <p>FSD6 - press the logo, enter the code (from 1 to 5 numbers), press the logo for confirmation, the display shows the numeric code.</p> <p>- wait for 2 minutes or press the ESC button.</p> <p>Note: if the badge and the numeric code is not recognized the display shows the message UNKN.</p>
<b>TERA</b> TAG TOTAL ERASE	<p>How to erase all stored badges and numeric codes. Choose between the following values:</p> <p><b>NO (*) = no erase</b></p> <p>YES = cancellation of all badges and numeric codes</p>
<b>SAM1</b> SELECTOR AUTOMATIC MODE	<p>First setting of function selector, when the 1-G1 / G2 / G3 / G4 contact becomes closed. Set the menu ADV &gt; STG1 / STG2 / STG3 / STG4 &gt; SAM.</p> <p>Connect the contact of a clock to 1-G1 / G2 / G3 / G4 terminals, and choose between the following values:</p> <p>OPEN = open door</p> <p>AUTO = automatic bi-directional operation</p> <p><b>CLOS (*) = closed door</b></p> <p>1D = automatic one-way operation</p> <p>PA = automatic partial operation</p> <p>1DPA = automatic one-way operation and partial</p>
<b>SAM2</b> SELECTOR AUTOMATIC MODE	<p>Second setting of function selector, when the 1-G1 / G2 / G3 / G4 contact becomes open. Set the menu ADV &gt; STG1 / STG2 / STG3 / STG4 &gt; SAM.</p> <p>Connect the contact of a clock to 1-G1 / G2 / G3 / G4 terminals, and choose between the following values:</p> <p>OPEN = open door</p> <p>AUTO = automatic bi-directional operation</p> <p><b>CLOS (*) = closed door</b></p> <p>1D = automatic one-way operation</p> <p>PA = automatic partial operation</p> <p>1DPA = automatic one-way operation and partial</p>
<b>FW</b> FIRMWARE UPGRADE	<p>Programming procedure of function selector.</p> <p>Insert the USB/micro SD memory in the electronic control.</p> <p>From this menu, choose the firmware version you want.</p> <p>Press ENTER until it starts the programming procedure that lasts about 30 seconds, at the end the display shows "SAVE".</p> <p>After the procedure, switch the power supply off and on again. Remove the USB/micro SD memory from the electronic control and store it for future use.</p> <p>Note: in the case of programming error or missing firmware (W103), proceed as follows: disconnect the power supply, insert the USB/micro SD memory, give power supply, and repeat the programming procedure from this menu.</p>
<b>VER</b> VERSION	<p>Displaying the firmware version of function selector.</p>
<b>TIN</b> TAG INPUT	<p>You can upload the badges and numeric codes used in another automation, already stored in the USB/micro SD memory. Choose between the following values:</p> <p><b>NO (*) = no upload</b></p> <p>YES = upload the badges and numeric codes from the USB/micro SD memory</p>
<b>TOUT</b> TAG OUTPUT	<p>You can save the stored badges and numeric codes in the USB/micro SD memory. Choose between the following values:</p> <p><b>NO (*) = no save</b></p> <p>YES = save the stored badges and numeric codes in the USB/micro SD memory</p>
<b>STCL</b> CLOSED DOOR SIGNAL	<p>Set the signaling of closed and locked door, with bistable locking device and microswitch. Choose from the following values:</p> <p><b>NO (*) = the symbol "closed door" remains lit even if the door is opened by hand.</b></p> <p>YES = the symbol "closed door" lights up only when the door is really closed and locked.</p> <p>Note: if the locking device does not close the door, the symbol "closed door" flashes.</p>

## 6.4 MEM (MEMORY MANAGEMENT MENU)

Using the buttons ↑ and ↓ select MEM, press ENTER to select and adjust the following parameters.

(\*) Factory settings








Display	Description
<b>FSET</b> FACTORY SETTINGS	Restore all settings to factory defaults. Choose between the following values: <b>NO (*) = no restore.</b> YES = restore to factory settings.
<b>FW</b> FIRMWARE UPGRADE	Programming procedure of electronic control. Insert the USB/micro SD memory in the electronic control. From this menu, choose the firmware version you want. Press ENTER until it starts the programming procedure that lasts about 30 seconds, at the end the display shows "SAVE". After the procedure, switch the power supply off and on again. Remove the USB/micro SD memory from the electronic control and store it for future use. Note: in the case of programming error or missing firmware (W100, W104), proceed as follows: disconnect the power supply, insert the USB/micro SD memory, give power supply, the programming procedure starts automatically, or choose the firmware from this menu.
<b>SIN</b> SETTING INPUT	You can upload the menu settings used in another automation, already stored in the USB/micro SD memory. Choose between the following values: <b>NO (*) = no upload</b> YES = upload the menu settings from the USB/micro SD memory
<b>SOUT</b> SETTING OUTPUT	You can save the menu settings of automation in use, in the USB/micro SD memory. Choose between the following values: <b>NO (*) = no save</b> YES = save the menu settings of automation in the USB/micro SD memory

## 6.5 INFO (INFORMATION AND DIAGNOSTICS MENU)

Using the buttons ↑ and ↓ select INFO, press ENTER to select and adjust the following parameters.

(\*) Factory settings

Display	Description
<b>SHOW</b> DISPLAY INFO	Displaying information of warning and faults. Choose between the following values: <b>CONT (*) = the display shows the active contacts of the terminal blocks and the alarms</b> WARN = the display shows the alarms only
<b>VER</b> VERSION	Displaying the firmware version of electronic control.
<b>CYCL</b> CYCLES	Shows the number of cycles of the door (1 = 1.000 cycles, 9000 = 9.000.000 cycles).
<b>SERV</b> SERVICE SIGNAL	Enabling the signaling of routine maintenance of the door. <b>NO (*) = no signaling</b> 1 = 1.000 cycles / 9000 = 9.000.000 cycles
<b>LOG</b> INFO FILE	You can save the following information in the USB/micro SD memory (sliding_log.txt): the last 20 warnings, the menu settings, and the electronic devices connected to automation. Choose between the following values: <b>NO (*) = no save</b> YES = save the information in the USB/micro SD memory
<b>WARN</b> WARNING LIST	Displaying of the last 10 warnings (the warning number 0 is the last): 0.xxx / 1.xxx / 2.xxx / 3.xxx / 4.xxx / 5.xxx / 6.xxx / 7.xxx / 8.xxx / 9.xxx

DISPLAY	SEL	FLASH	WARNING	CHECK
W001		1	Encoder error	Check encoder connection
W002		1	Motor short circuit	Check the connection of the motor
W003		1	Motor control error	Electronic control failure
W010		2	Direction reversed	Check the presence of obstacles
W011		2	Running too long	Check the connection of the belt
W012		2	Running too short	Check the presence of obstacles
W013		2	Overrun	Check the mechanical stops

DISPLAY	SEL	FLASH	WARNING	CHECK
W100	-	-	Programming error	Repeat the programming procedure in MEM > FW menu
W103	-	-	Programming selector error	Repeat the programming procedure in SEL > FW menu
W110		1	Internal memory error	Electronic control failure
W127	-	-	Automation reset	The automation performs a self-test
W128		on	No power supply	Check the power supply
W129		1	No battery	Check the battery connection
W130		1	Low Battery	Replace or recharge the battery
W131		1	Error of Supercapacitor	Check the connection Supercapacitor - electronic control
W140		3	6A safety test failure	Check the safety sensor connection
W141		3	6B safety test failure	Check the safety sensor connection
W142		3	8A safety test failure	Check the safety sensor connection
W143		3	8B safety test failure	Check the safety sensor connection
W145		4	Motor overtemperature (first step)	The door reduces the speed
W146		4	Motor overtemperature (second step)	The door stops
W148		1	Locking device overcurrent	Check the ADV > TYLK menu and the lock connection
W150		2	Obstacle in opening	Check the presence of obstacles
W151		2	Obstacle in closing	Check the presence of obstacles
W152		2	Door locked open	Check the presence of locks
W153		2	Door locked closed	Check the presence of locks
W160		1	Synchronization error	Check the ADV > SYNC and ADV > INK menu
W256	-	-	Power on	-
W257	-	-	Firmware update	-
W320		on	Signaling of maintenance	Check the INFO > SERV menu
W330		1	Tuning between motor and electronics	Wait about 3-30 seconds


## 6.6 LOW ENERGY

To reduce the force and kinetic energy of the door, make the following adjustments.

Adjust the force PUSH  $\leq 5$ .

Adjust the opening speed (VOP) so as to open the door (90%) at the times indicated in the table.

Adjust the closing speed (VCL) so as to close the door (90%) at the times indicated in the table.



D [m]	Door weight [kg]														
	150	140	130	120	110	100	90	80	70	60	50	40	30	20	10
	Maximum speed [m/s]														
	0,15	0,16	0,16	0,17	0,18	0,18	0,19	0,21	0,22	0,24	0,26	0,29	0,34	0,41	0,58
Time [s]															
0,7	4,7	4,6	4,4	4,2	4,0	3,9	3,7	3,5	3,2	3,0	2,7	2,5	2,1	1,8	1,3
0,8	5,4	5,2	5,0	4,8	4,6	4,4	4,2	3,9	3,7	3,4	3,1	2,8	2,4	2,0	1,4
0,9	6,0	5,8	5,6	5,4	5,2	4,9	4,7	4,4	4,1	3,8	3,5	3,1	2,7	2,2	1,6
1,0	6,7	6,5	6,3	6,0	5,8	5,5	5,2	4,9	4,6	4,3	3,9	3,5	3,0	2,5	1,8
1,1	7,4	7,1	6,9	6,6	6,3	6,0	5,7	5,4	5,1	4,7	4,3	3,8	3,3	2,7	1,9
1,2	8,0	7,8	7,5	7,2	6,9	6,6	6,2	5,9	5,5	5,1	4,7	4,2	3,6	3,0	2,1
1,3	8,7	8,4	8,1	7,8	7,5	7,1	6,8	6,4	6,0	5,5	5,0	4,5	3,9	3,2	2,3
1,4	9,4	9,1	8,7	8,4	8,0	7,7	7,3	6,9	6,4	5,9	5,4	4,9	4,2	3,5	2,5
1,5	10,0	9,7	9,4	9,0	8,6	8,2	7,8	7,3	6,9	6,4	5,8	5,2	4,5	3,7	2,6

## 7. START-UP PROCEDURE OF THE HERMETIC SLIDING DOOR

### 7.1 Preliminary checks.

At the end of the installation, move the doors manually and make sure that operation is smooth and without friction. Check the solidity of the structure and the proper attachment of all the screws. Check the correctness of all electrical connections.

Before connecting any security devices, leave the jumper on terminals safety (41-8A, 41-8B, 41-6A, 41-6B, 1-S1).

### 7.2 Giving power supply and connect the battery, if present.

Note: every time you switch on the automation performs a self-test (from 3 to 30 seconds). The first opening and closing cycle is at low speed to allow the automatic learning.

To ensure that the electronic control has the factory settings, restore via the menu:

MEM > FSET = YES (confirm by pressing ENTER for 1 second).

Select the type of door using the menu:

MENU > DOOR = HSTD for hermetic doors up to 100 kg, or

MENU > DOOR = HBIG for hermetic doors up to 200 kg

Note: if the door is 1-leaf opening to the left, set the opening direction as follows:

MENU > OPEN = ← (confirm by pressing ENTER for 1 second).

Perform the menu settings as described in Chapter 6. Use OPEN button to perform the opening door, and verify the correct operation of the door.

Note: the automation automatically detects any obstacles during the closing movement (reversal movement) and opening (stopping movement).

### 7.3 Connect one at a time, opening and safety devices to protect the closing cycle of the door, as described in Chapter 5.5, and verify proper operations.

Note: verify that the opening access is properly protected by safety sensors, in accordance with the requirements of the European standard EN16005 (annex C).



Connect one at a time, safety devices to protect the opening cycle of the door, as described in Chapter 5.6, and verify proper operations.

Note: if the gap between the door and the fixed parts meet the requirements of the European standard EN16005 (Chapter 4.6.2.1.a), the safety sensors are not needed ( $X \leq 100$  e  $Y \geq 200$ ).

### 7.4 At the end of the automation starting, deliver to the owner the user instructions, including all warnings and information necessary to maintain the security and functionality of the automatic door.

Automations are feature of label on the right end cap, containing the required information by European standards EN16005 and EN60335-2-103.

Note: the manufacturer of the automatic sliding door have to add his own label identifying the installation.



<b>FACE S.r.l.</b>	www.facespa.it
Viale delle Industrie, 74 - 31030 Dosson di Casier (TV)	
Type: <b>SL6HA</b>	Standard: EN16005
DRIVE UNIT FOR SLIDING DOOR	
Input: 100-240V 50/60Hz Power: 70W	
Load: 150N S3: 60%	
Tmin: -15°C Tmax: +50°C IP20	
KSL6HA1R s/n: 1810 0011 Year: 2018	
	
made in Italy 0063518100011	

## 8. TROUBLESHOOTING

In addition to the following list of possible problems, there are warnings provided by the display, as described in chapter 6.5.

Problem	Possible causes	Remedy
The automation does not open or close.	No power supply (display off).	Check the power supply.
	Blow line fuse (display off).	Replace the mains fuse.
	Short circuited external accessories.	Disconnect all accessories from terminals 0-1 and reconnect them one at a time (check for voltage 12V).
	The door is locked by bolts and locks.	Check the freely move of the doors
The automation does not perform the functions set.	Function selector incorrectly set.	Check and correct the settings of the function selector.
	Control devices or safety always activated.	Disconnect devices from the terminal and verify the operation of the door.
The movement of the doors isn't linear, or reverse the movement for no reason.	The automation does not successfully perform the automatic learning.	Perform a reset using the command 1-29 , or power off and power on the automation.
The automation opens but does not close	Anomalies during the safety devices test.	Jumper contacts one at a time 41 -8A , 41 -8B , 41 - 6A, 6B - 41 .
	The opening devices are activated.	Verify that the opening sensors are not subject to vibration , do not perform false detections or the presence of moving objects in the field of action.
	The automatic closing doesn't work.	Check the settings of the function selector .
Safety devices not activating.	Incorrect connections between the safety devices and electronic control.	Check that the safety contacts of the devices are properly connected to the terminal blocks and the relative jumpers have been removed.
The automation opens by itself.	The opening and safety devices are unstable or detect moving bodies	Verify that the opening sensors are not subject to vibration , do not perform false detections or the presence of moving bodies in the field of action.

## 9. AUTOMATIC SLIDING DOOR ROUTINE MAINTENANCE PLAN

To ensure proper operation and safe use of the automatic door, as required by European standard EN16005, the owner has to perform routine maintenance by qualified personnel. Except for routine cleaning of the door and any floor rails, that are under the responsibility of the owner, all maintenance and repair work must be carried out by qualified personnel. The following table lists tasks related to routine maintenance, and the frequency of intervention related to an automatic sliding door operation with standard conditions. In the case of more severe operating conditions, or in the case of sporadic use of the automatic sliding door, the frequency of maintenance can be consistently adequate.

Task	Frequency
Remove the power supply, open the automation and perform the following checks and adjustments. - Check all screws fastening of components within the automation. - Check the cleanliness of carriage and rail. - Check the correct belt tension. - Check the state of belt wear and carriage wheels (if necessary replace them). - Check the correct fitting of the doors on the carriages.	Every 6 months or every 20.000 cycles.
Connect the power supply and perform the following checks and adjustments. - Check the correct operation of the control devices and safety. - Check the detection area of the security sensors complies with the requirements of the European standard EN16005. - If present, verify the correct operation of the battery power device (if necessary replace the battery).	Every 6 months or every 20.000 cycles. Note: the verification of the automation security functions and safety devices must be made at least 1 time per year.

All maintenance, replacement, repair, update, etc. must be written into the proof book, as required by European standard EN16005, and delivered to the owner of the automatic sliding door. For repairs or replacements of products, original spare parts must be used.

### 9.1 DISPOSAL OF PRODUCTS



The packaging materials (cardboard, plastic, and so on) should be disposed of as solid household waste, and simply separated from other waste for recycling. Our products are made of various materials. Most of these (aluminum, plastic, iron, electrical cables) are classified as solid household waste. They can be recycled by separating them before dumping at authorized city plants. Whereas other components (control boards, batteries, and so on) may contain hazardous pollutants. These must therefore be disposed of by authorized, certified professional services. Before disposing, it is always advisable to check with the specific laws that apply in your area. DO NOT DISPOSE IN THE ENVIRONMENT.

### DECLARATION OF INCORPORATION (FOR UK MARKET ONLY)

The Supply of Machinery (Safety) Regulations 2008, Annex II-B

**UK  
CA**

FACE S.r.l. - Viale delle Industrie, 74 - 31030 Dosson di Casier (TV) - ITALY

Declares that the Product automations for power operated pedestrian sliding door type: SL6HA, SL6HB.

Has been built for installation on pedestrian door and constitutes a machine in accordance with The Supply of Machinery (Safety) Regulations 2008. The manufacturer of the power operated pedestrian door must declare its conformity in accordance with The Supply of Machinery (Safety) Regulations 2008, prior to starting-up the machine.

It complies with the applicable essential safety requirements specified in The Supply of Machinery (Safety) Regulations 2008, Annex I: 1.1.2, 1.1.3, 1.2, 1.3.1, 1.3.2, 1.3.4, 1.3.7, 1.3.8, 1.4, 1.5.1, 1.5.2, 1.5.10, 1.5.11, 1.5.14, 1.6.1, 1.6.3, 1.7

It complies with the Electromagnetic Compatibility Regulations 2016.

It complies with following harmonized standards:

EN 16005 Power operated pedestrian doorsets - Safety in use - Requirements and test methods

EN 60335-2-103 Household and similar electrical appliances - Safety - Part 2: Particular requirements for drives for gates, doors and windows

The technical documentation complies with The Supply of Machinery (Safety) Regulations 2008, Annex VII-B.

The technical documentation is managed by: Ferdinando Menuzzo with registered offices in Viale delle Industrie, 74 - 31030 Dosson di Casier (TV) - ITALY

A copy of the technical documentation shall be supplied to the competent national authorities following duly motivated request.

Place and date:

Dosson di Casier, 2022-10-01

Paolo Bacchin  
Managing Director